



ILLURE®

ILLUMINATE *the* MOMENT™

Dear Valued Customers,

Thank you for purchasing an ILLURE® Real Wax Candle. As with any traditional candle, care is required to maintain your ILLURE® Candle. For best performance, please take the time to read the instructions inside. Thank you for choosing our product.


BATTERY INSTALLATION & MAINTENANCE

1,200 hours of battery life on two (2) D batteries

- Your candle requires two (2) D batteries (sold separately).
- Turn candle over and remove cover from the battery compartment.
- Insert two (2) D batteries in the battery compartment.
- Replace battery compartment cover.

LOW BATTERY INDICATOR


Your ILLURE® Candle will begin flashing/blinking when the batteries are too weak to properly power the candle. Replace the batteries if your candle begins flashing/blinking.



Remove batteries once they have run out of power or if the product has been left unused for an extended period of time.

OPERATION ON/OFF

To turn the candle on, Slide the Switch on the bottom of the candle to the ON Position. To turn the candle off, Slide the Switch on the bottom of the candle to the OFF Position.



TIMER

To set the timer, Slide the Switch on the bottom of the candle to the Timer Position. The candle will remain on for four (4) hours from the time that you place the candle in "TIMER" mode.

After four (4) hours of run time the candle will automatically turn off for twenty (20) hours. It will repeat the same cycle daily until the user resets the timer. To reset the timer, slide the switch to the ON position and then slide back to the Timer position.

Candle may be used with an ILLURE® remote control. The timer function can also be activated from the remote control.

REMOTE FUNCTIONS

Your ILLURE® remote has (4) timer settings – 4hr, 6hr, 8hr and 10hr. These all operate on a 24 hr format. You remote also has a Patented Inner Glow feature. This will allow you to adjust the brightness of the inside of the candle at any time. Simply just

use the - / + feature on the remote to set to your desired brightness.

****TO OPERATE THE REMOTE CONTROL WITH THE CANDLE PLEASE MAKE SURE THE SWITCH ON THE BOTTOM OF THE CANDLE IS MOVED INTO THE "ON" POSITION****

GENERAL CARE

Clean as needed with a soft, dry cloth.

® & ©2020 Luminous Innovations, Inc
Estd 2019

Portola Valley, CA USA
www.illure.com/patents

Designed in San Francisco, Made in Vietnam

LIMITED WARRANTY

Your **ILLURE**[®] candle is guaranteed to be free from manufacturing defects for a period of ninety (90) days from the date of purchase. We will replace your defective **ILLURE**[®] candle with the same or similar item. This warranty does not cover damage due to neglect, misuse, exposure to excessive heat or improper battery installation. Please contact us by e-mail at mail@illure.com for warranty information. Proof of purchase is required.

CAUTION

Your **ILLURE**[®] Candle is made of Real Wax and is flammable. Do not attempt to light. Doing so could result in personal injury or damage to the light and electrical components. Your

ILLURE[®] Candle is intended for Indoor use. Keep away from heat sources and out of extreme temperatures. Doing so may result in damage to the components or the wax and will void the warranty. **ILLURE**[®] candles and Lanterns are breakable. Dropping can break or damage the candle and can also damage internal components, voiding the warranty.

This product contains small parts, which, if removed, can pose a choking hazard. Keep away from small children. Insert batteries as displayed on the battery compartment. Failure to insert the batteries correctly may result in damage to your candle or personal injury and will void the warranty. Do not mix old and new batteries. Do not mix Alkaline, Carbon-Zinc, NiMhd, or NiCad batteries. Please recycle used batteries or

dispose of them as per state and local guidelines. Do not dispose of batteries in fire. Always purchase the correct size and grade of battery most suitable for the intended use. Replace all batteries a set at the same time. Clean the battery contacts and also those of the device prior to battery installations. Ensure the batteries are installed correctly with regard to polarity (+ and -).

FCC COMPLIANCE

NOTE: This device has been tested and found to comply with the limits for a class B digital device pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential

installation. The device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. There is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning this device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between this device and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WWW.ILLURE.COM